

TrackSense® Pro Multi Reader Station



TrackSense® Pro Single Reader Station



Technical specification	Multi Reader Station	Single Reader Station
Operating Temperature	5 °C to 50 °C/ 41 °F to 122 °F	5 °C to 50 °C/ 41 °F to 122 °F
Operating Voltage	5V External Adapter 100-240 V AC, 50-60 Hz or USB	5V External Adapter 100-240 V AC, 50-60 Hz or USB
Environmental:	0 - 90% RH, non-condensing	0 - 90% RH, non-condensing
Reader / Logger Communication	Induction	Induction
PC Interface:	USB / LAN Connection	USB
Capacity:	1-4 Loggers at a Time	1 Loggers at a Time
Expansion:	Up to 4 modules	-
Expansion Capacity:	Up to 16 loggers at a time	-